

[Advance Preparation]

- If there are any accompanying software with Bluetooth USB adapter, install the accompanying software.
- Pair the printer used with Bluetooth.

[Operation of connecting to driver]

<EX Driver>

- Refer to "Serial (COM) connection" in "Installation Procedure" of "Setting Guide."

<_DS Driver>

- Refer to "Installation" in "Windows 8 Installation/Setting Manual."

[Restriction] (* Make sure to read before using)

<EX Driver>

- Refer to "Restriction" in "Setting Guide."
- Refer to "Restriction" in "Overview" of "Installation Guide."

<_DS Driver>

- Refer to "Restriction" in "Please be sure to read before use."